

## INSTALLATION/ASSEMBLY RECOMMENDATIONS


### LOW BALANCE BEAM PADS

**NOTE: READ THESE RECOMMENDATIONS COMPLETELY BEFORE STARTING TO INSTALL OR ASSEMBLE THIS**

1. Included in this packet should be 2 carpeted beam legs, 4 lag bolts and 4 washers.
2. You will need a 9/16" wrench or ratchet wrench with a 9/16" socket.
3. Line up holes in pads with holes on bottom of beam.
4. Insert lag bolt with washer into each hole and bolt pad tightly to beam (do not over tighten bolts).
5. When both pads are securely fastened to beam, place the beam on a flat surface and check stability.

Slight instabilities can be adjusted with a 1/2 turn on one side or the other.

#### Low Practice Beam Leg Mounting Instructions



**RISK OF SERIOUS INJURY, PARALYSIS AND/OR DEATH, IS INHERENT IN ALL ACTIVITIES INVOLVING MOTION OR HEIGHT. THIS EQUIPMENT IS TO BE USED ONLY BY PROPERLY TRAINED, QUALIFIED PERSONS UNDER SUPERVISED CONDITIONS. USE WITHOUT PROPER SUPERVISION IS DANGEROUS AND SHOULD NEVER BE UNDERTAKEN NOR PERMITTED. NORBERT'S ATHLETIC PRODUCTS, INC. SHALL NOT BE LIABLE NOR RESPONSIBLE FOR PERSONAL INJURY OR PROPERTY DAMAGE INCURRED THROUGH THE USE OR MISUSE OF THIS EQUIPMENT OR ANY OTHER PRODUCT MANUFACTURED BY NORBERT'S ATHLETIC PRODUCTS, INC.**